

Fig. 1




Fig. 2




Fig. 3




Fig. 4




Fig. 5




Fig. 6




Fig. 7




Fig. 8




Fig. 9




Fig. 10




Fig. 11




Fig. 12




Fig. 13

Fig. 13 is a perspective view of a portable electronic device 1, showing a top surface 81 with a display 83, a keypad 74, and a control panel 76. The device has a front face 21 with a speaker 22 and a microphone 23. A side panel 93a is visible, and a base 16 is shown at the bottom. Various components are labeled with reference numerals: 1, 16, 17, 18, 19, 20, 21, 22, 23, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 93a, 94, 95, 96, 97, 98, 99, 100.

F

Fig. 14




Fig. 16





Fig. 17



E

Fig. 18




Fig. 19





Fig. 20






Fig. 21




Fig. 22




Fig. 23




Fig. 24




Fig. 25




Fig. 26




Fig. 27




Fig. 28




Fig. 29




Fig. 30




Fig. 31